

# The Bit



Fifth Edition

UNIT I • LESSON 2



## ROTARY DRILLING SERIES

### Unit I: The Rig and Its Maintenance

- Lesson 1: The Rotary Rig and Its Components
- Lesson 2: The Bit
- Lesson 3: Drill String and Drill Collars
- Lesson 4: Rotary, Kelly, Swivel, Tongs, and Top Drive
- Lesson 5: The Blocks and Drilling Line
- Lesson 6: The Drawworks and the Compound
- Lesson 7: Drilling Fluids, Mud Pumps, and Conditioning Equipment
- Lesson 8: Diesel Engines and Electric Power
- Lesson 9: The Auxiliaries
- Lesson 10: Safety on the Rig

### Unit II: Normal Drilling Operations

- Lesson 1: Making Hole
- Lesson 2: Drilling Fluids
- Lesson 3: Drilling a Straight Hole
- Lesson 4: Casing and Cementing
- Lesson 5: Testing and Completing

### Unit III: Nonroutine Operations

- Lesson 1: Controlled Directional Drilling
- Lesson 2: Open-Hole Fishing
- Lesson 3: Blowout Prevention

### Unit IV: Man Management and Rig Management

### Unit V: Offshore Technology

- Lesson 1: Wind, Waves, and Weather
- Lesson 2: Spread Mooring Systems
- Lesson 3: Buoyancy, Stability, and Trim
- Lesson 4: Jacking Systems and Rig Moving Procedures
- Lesson 5: Diving and Equipment
- Lesson 6: Vessel Inspection and Maintenance
- Lesson 7: Helicopter Safety
- Lesson 8: Orientation for Offshore Crane Operations
- Lesson 9: Life Offshore
- Lesson 10: Marine Riser Systems and Subsea Blowout Preventers

# Contents

Figures	vii
Foreword	ix
Preface	xi
Acknowledgments	xiii
About the Author	xv
Units of Measurement	xvi
Introduction	1
To summarize	3
Bit Selection	5
Factors to Consider	5
Formation and Lithology	6
Rate of Penetration	7
Durability and Longevity	7
Gauge	7
Cost	8
To summarize	8
Roller Cone Bits	9
History	11
Types of Roller Cone Bits	13
Steel-Tooth Bits	13
Tungsten Carbide Insert Bits	14
Powder-Forged Bits	15
Manufacture and Design	16
Cones	17
Cone Alignment	18
Interfit	20
Journal Angle	20
Cutting Structures	21
Steel Teeth	21
Tungsten Carbide Inserts	22
Powder-Forged Cutting Structures	23
Bit Gauge	24
Drilling Fluid and Hydraulics	26
Reactive and Nonreactive Materials	27
Air and Gas Drilling Fluids	27
Cleaning	28
Watercourses	28
Jet Nozzles	28
Hydraulic Horsepower	30
Bearings	31
Cone Retention Systems	32
Roller Bearing Bits	32
Journal Bearing Bits	34



Petroleum Extension-The University of Texas at Austin

Bearing Lubrication	36
Wear	38
Cone Wear	39
Cutting Structure Wear	42
Bearing Wear	48
Other Types of Wear	49
To summarize	51
Diamond Bits	53
Properties of Diamonds	54
Extreme Hardness	54
High Strength and Elasticity	54
Good Thermal Conductivity	55
Low-Friction Force	55
Thermal Instability	55
Low-Impact Shock	56
Natural and Diamond Impregnated Bits	56
Manufacture and Design	57
Profiles	58
Cutting Structure	60
Hydraulics	62
PDC Bits	64
Manufacture and Design	64
Profiles	65
PDC Cutters	66
Hydraulics	71
Features of New Bit Designs	72
Other PDC Bit Components	74
Wear	76
Bit Whirl and Lateral Vibration	77
PDC Cutter Wear	80
To summarize	81
Special-Purpose Bits	83
Roller Cone Bits	83
Fixed-Cutter Bits	85
To summarize	88
Formations and Bit Performance	89
Formation Properties	90
Formation Analysis	91
Analyze Seismic Data	91
Examine a Core	91
Review Data	91
Test the Formation	91
How Bits Drill	92
To summarize	93
WOB, Rotary Speed, and ROP	95

Roller Cone Bits	96
Diamond Bits	97
To summarize	98
Bit Classification	99
Roller Cone Bits	100
Diamond Bits	102
To summarize	105
Dull Bit Grading	107
To summarize	111
Expenses to Consider	113
To summarize	114
Field Operating Procedures	115
Drilling with a Roller Cone Bit	115
Drilling with a Diamond Bit	116
To summarize	118
Conclusion	119
Appendices	121
Glossary	133
Review Questions	151
Index	157
Answer Key	165

Petroleum Extension-The University of Texas at Austin



## About the Author



**F**rom Europe to Africa to the Commonwealth of Independent States, Mark Jordan has supervised a number of engineering groups in the field, confronting a wide variety of bit applications and design specifications. He has over 35 years of experience in the oil industry, performing roles ranging from mud logging, core analysis, engineering, sales, and senior management. Over the past two decades, Mark has assumed key positions at Schlumberger, ReedHycalog, and National Oilwell Varco (NOV), devoting much of his career to the bit and other downhole tool product lines. In his current role at NOV, Mark is committed to transferring his background and experiences to the next generation of industry professionals, providing new employees with the support and knowledge they need for understanding bit applications, selection, bottomhole assembly, and techniques for maximizing drilling performance.

Mark holds a B.S. Honours degree in Geology from the University of Dundee in the United Kingdom and is a member of the Society of Petroleum Engineers (SPE) and the Fellowship Geological Society (FGS).

# Units of Measurement



Throughout the world, two systems of measurement dominate: the English system and the metric system. Today, the United States is one of only a few countries that employ the English system.

The English system uses the pound as the unit of weight, the foot as the unit of length, and the gallon as the unit of capacity. In the English system, for example, 1 foot equals 12 inches, 1 yard equals 36 inches, and 1 mile equals 5,280 feet or 1,760 yards.

The metric system uses the gram as the unit of weight, the metre as the unit of length, and the litre as the unit of capacity. In the metric system, 1 metre equals 10 decimetres, 100 centimetres, or 1,000 millimetres. A kilometre equals 1,000 metres. The metric system, unlike the English system, uses a base of 10; thus, it is easy to convert from one unit to another. To convert from one unit to another in the English system, you must memorize or look up the values.

In the late 1970s, the Eleventh General Conference on Weights and Measures described and adopted the Systeme International (SI) d'Unites. Conference participants based the SI system on the metric system and designed it as an international standard of measurement.

The Rotary Drilling Series gives both English and SI units. And because the SI system employs the British spelling of many of the terms, the book follows those spelling rules as well. The unit of length, for example, is metre, not meter. (Note, however, that the unit of weight is gram, not gramme.)

To aid U.S. readers in making and understanding the conversion system, we include the table on the next page.

## English-Units-to-SI-Units Conversion Factors

Quantity or Property	English Units	Multiply English Units By	To Obtain These SI Units
Length, depth, or height	inches (in.)	25.4	millimetres (mm)
		2.54	centimetres (cm)
	feet (ft)	0.3048	metres (m)
	yards (yd)	0.9144	metres (m)
	miles (mi)	1609.344	metres (m)
		1.61	kilometres (km)
Hole and pipe diameters, bit size	inches (in.)	25.4	millimetres (mm)
Drilling rate	feet per hour (ft/h)	0.3048	metres per hour (m/h)
Weight on bit	pounds (lb)	0.445	decanewtons (dN)
Nozzle size	32nds of an inch	0.8	millimetres (mm)
Volume	barrels (bbl)	0.159	cubic metres (m <sup>3</sup> )
		159	litres (L)
	gallons per stroke (gal/stroke)	0.00379	cubic metres per stroke (m <sup>3</sup> /stroke)
	ounces (oz)	29.57	millilitres (mL)
	cubic inches (in. <sup>3</sup> )	16.387	cubic centimetres (cm <sup>3</sup> )
	cubic feet (ft <sup>3</sup> )	28.3169	litres (L)
		0.0283	cubic metres (m <sup>3</sup> )
	quarts (qt)	0.9464	litres (L)
	gallons (gal)	3.7854	litres (L)
	gallons (gal)	0.00379	cubic metres (m <sup>3</sup> )
	pounds per barrel (lb/bbl)	2.895	kilograms per cubic metre (kg/m <sup>3</sup> )
barrels per ton (bbl/tn)	0.175	cubic metres per tonne (m <sup>3</sup> /t)	
Pump output and flow rate	gallons per minute (gpm)	0.00379	cubic metres per minute (m <sup>3</sup> /min)
	gallons per hour (gph)	0.00379	cubic metres per hour (m <sup>3</sup> /h)
	barrels per stroke (bbl/stroke)	0.159	cubic metres per stroke (m <sup>3</sup> /stroke)
	barrels per minute (bbl/min)	0.159	cubic metres per minute (m <sup>3</sup> /min)
Pressure	pounds per square inch (psi)	6.895	kilopascals (kPa)
		0.006895	megapascals (MPa)
Temperature	degrees Fahrenheit (°F)	$\frac{°F - 32}{1.8}$	degrees Celsius (°C)
Mass (weight)	ounces (oz)	28.35	grams (g)
	pounds (lb)	453.59	grams (g)
		0.4536	kilograms (kg)
	tons (tn)	0.9072	tonnes (t)
	pounds per foot (lb/ft)	1.488	kilograms per metre (kg/m)
Mud weight	pounds per gallon (ppg)	119.82	kilograms per cubic metre (kg/m <sup>3</sup> )
	pounds per cubic foot (lb/ft <sup>3</sup> )	16.0	kilograms per cubic metre (kg/m <sup>3</sup> )
Pressure gradient	pounds per square inch per foot (psi/ft)	22.621	kilopascals per metre (kPa/m)
Funnel viscosity	seconds per quart (s/qt)	1.057	seconds per litre (s/L)
Yield point	pounds per 100 square feet (lb/100 ft <sup>2</sup> )	0.48	pascals (Pa)
Gel strength	pounds per 100 square feet (lb/100 ft <sup>2</sup> )	0.48	pascals (Pa)
Filter cake thickness	32nds of an inch	0.8	millimetres (mm)
Power	horsepower (hp)	0.75	kilowatts (kW)
Area	square inches (in. <sup>2</sup> )	6.45	square centimetres (cm <sup>2</sup> )
	square feet (ft <sup>2</sup> )	0.0929	square metres (m <sup>2</sup> )
	square yards (yd <sup>2</sup> )	0.8361	square metres (m <sup>2</sup> )
	square miles (mi <sup>2</sup> )	2.59	square kilometres (km <sup>2</sup> )
	acre (ac)	0.40	hectare (ha)
Drilling line wear	ton-miles (tn•mi)	14.317	megajoules (MJ)
		1.459	tonne-kilometres (t•km)
Torque	foot-pounds (ft•lb)	1.3558	newton metres (N•m)



Petroleum Extension: The University of Texas at Austin



# Introduction




*In this chapter:*

- An overview on how bits are used
- Cutting structures and diamond cutters
- Drilling fluid circulation
- Range of bit sizes

The *bit* is a rotating device located at the bottom of a *drill string*. It is used to cut and dislodge layers of underground rock (fig. 1). As the bit rotates, cutting structures in the form of steel teeth, inserts, diamonds, or diamond compacts (called *cutters*) chip away at the rock (fig. 2). As the rock is cut, *drilling fluid*, in the form of air, gas, water, oil-based mud, or a variety of substances, is circulated through the bit to displace the broken material (fig. 3). The small, fragmented pieces of rock, referred to as *cuttings*, travel through the *annular space* in the *borehole* back to the earth's surface.

Bits are available in various sizes. Most bits are 26 inches (660 millimetres) or less in diameter, although sizes range from 3 inches (76 millimetres) to 42 inches (1,067 millimetres). As detailed in subsequent sections of this book, a number of factors influence the size and type of bit that is selected. A thorough evaluation of these factors can help ensure the success of a drilling operation.



*Figure 1. A bit is designed to cut through layers of rock.*

# Bit Selection



---

*In this chapter:*

- How formations and lithology impact bit selection
  - Rate of penetration, durability, and longevity
  - The importance of drilling a full-gauge hole
  - The costs and benefits of high-quality bits
- 

Whether a company is drilling a *wildcat well* (the first well constructed in a particular area) or drilling in a known oil field, it is important that a rig operator or contractor choose a bit that is most appropriate for the job. Prior to selecting a bit, the operator should consider the following:

- *Formation and lithology*
- *Rate of penetration (ROP)*
- Durability and longevity
- Gauge
- Cost

The above factors play a critical role in the selection process. Therefore, it is important for operators to become familiar with the key terms and concepts identified throughout this chapter. Moreover, all those responsible for handling a bit can benefit prior to the commencement of a drilling operation by reviewing the criteria addressed within this section.

## Factors to Consider

# Roller Cone Bits



*In this chapter:*

- History of roller cone bits
- Types of roller cone bits
- Characteristics of bit cutting structures
- Drilling fluid and hydraulics
- Bit wear and prevention

Typically, a *roller cone bit* is equipped with three hollow, cone-shaped components (fig. 6). Some roller cone bits include one, two, or four *cones*. The cones of a roller cone bit are made of metal. Rows of teeth or *inserts* line the surface of the cones. Each cone is designed to rotate, or roll, on its own axis using *bearings* that are lubricated with drilling fluid or special grease (fig. 7). As the drill string rotates, contact with the formation causes the cones to rotate.



COURTESY OF SMITH BITS

Figure 6. A roller cone bit




Figure 7. Each cone of a roller cone bit rotates on its own axis.

# Diamond Bits



---

*In this chapter:*

- History of diamond (fixed-cutter) bits
  - Properties of diamond
  - Natural and synthetic diamond bits
  - Drilling fluid and hydraulics
  - Bit wear and prevention
- 

**D**iamond is the hardest naturally occurring mineral on earth. It is four times harder than the second hardest mineral, corundum. Diamonds can outwear or cut anything and remain unaffected. They can cut, grind, and polish hard materials with the utmost precision, which is why it's common to find tools set with whole or crushed diamonds in industries that demand a high level of strength and accuracy. For example, diamond tools are used in the optical industry to cut glass. Surgical instruments are often assembled with diamonds, and the automobile, aircraft, and space industries all rely on diamonds to manufacture vehicles. Diamond tools would be more common in every industry and home workshop if they were not so rare and expensive to mine.

Scientists first attempted to create a low-cost, synthetic diamond in 1797. In doing so, they considered carbon. Like coal, types of ash, and soft graphite used in pencils, diamond is pure carbon. In 1954, research scientists at General Electric were the first to successfully create a diamond out of carbon. As it turns out, synthetic diamonds were more expensive to produce than natural diamonds were to mine. However, manufacturers continue to produce synthetic diamonds because demand is so great and carbon is so plentiful.

---

Synthetic diamonds used today:

- Polycrystalline diamonds
  - Thermally stable polycrystallines (TSPs)
-

# Special-Purpose Bits



---

*In this chapter:*

- Drilling with air and gas
  - Jet deflection bits
  - Positive displacement tools and turbine motors
  - Preventing bit whirl
  - Eccentric and sidetracking bits
- 

In addition to standard roller cone and fixed-cutter bits, bits can be enhanced to serve a particular purpose. For example, some roller cone bits have extra hardfacing and tungsten carbide inserts on the shirrtail. This extra layer helps prevent wear and, if protruding, absorb lateral impacts. Likewise, some fixed-cutter bits come equipped with diamond impregnated gauge protection to improve wear resistance. Extended nozzles, which help prevent balling, are a popular option for roller cone bits that are used to drill soft formations.

Adding features to a bit can prevent wear and improve drilling efficiency.

Air or gas serves as the drilling fluid in so-called *air bits*. Air bits come equipped with sealed bearings that prevent them from becoming clogged with cuttings. A thick layer of hardfacing on the shirrtail protects these bits from the abrasive, high-velocity air or gas that is released. Manufacturers usually configure air bits with little or no skew angle, which also reduces gauge wear.

*Two-cone bits* might drill very soft formations faster than standard, three-cone bits. However, they might not last as long as three-cone bits.

## Roller Cone Bits

Air bits have:

- Sealed bearings
- Hardfacing
- Minimal or no skew angle

# Formations and Bit Performance



---

*In this chapter:*

- Understanding formation properties
- Achieving a high rate of penetration
- How roller cone and fixed-cutter diamond bits drill
- Ways in which manufacturers improve bit performance
- Penetrating soft and hard formations

---

To achieve the fastest penetration rate and best interval performance at the lowest possible cost, rig operators or contractors must select a bit that is right for the job. However, a number of factors predetermine a bit's performance, including:

- Formation type
- Weight and rotary speed
- Hydraulics

The above factors affect how well a bit will operate. Therefore, rig operators must analyze these and other factors before choosing a bit.

As discussed in the subsequent sections, an understanding of the properties of formations helps inform bit selection. Moreover, analyzing formations can provide drillers with data to help ensure a successful operation. Once formations have been evaluated and a bit has been selected, it is critical that drillers and the rig crew handle it properly to avoid unnecessary wear.

Bit performance is influenced by:

- Formation type
- Weight
- RPM
- Hydraulics

# WOB, Rotary Speed, and ROP



---

*In this chapter:*

- Controlling weight and rotary speed
  - Adjusting operations as bits wear
  - When to increase or decrease WOB
  - The ROP of natural diamond and PDC bits
- 

In order for a bit to perform at an optimum level, the WOB and rotary speed should be properly adjusted. In general, a higher rotary speed requires a lower WOB and vice-versa. Laboratory and field tests have shown that the optimum combination of weight and rotary speed varies between soft, medium, and hard formations. Moreover, different weights and rotary speeds can yield vastly different *drilling rates*. For example, by increasing the WOB of a steel-tooth bit by 30 to 40%, its rate of penetration can double. Typically, however, a rig operator or contractor does not simply want to improve the drilling rate for a short period of time. Rather, good, long-term performance should be the ultimate goal. This requires balanced parameters.

The following sections examine the WOB, RPM, and ROP of roller cone and diamond bits and provide guidelines for improving drilling efficiency in various formations.

---

Drilling rates can improve if the bit is operated with appropriate weight and rotary speeds.

---



# Bit Classification



---

*In this chapter:*

- How roller cone bits are classified
- How diamond bits are classified
- Examining the features of roller cone bits
- Examining the features of diamond bits
- Understanding classification codes

---

The IADC has developed a standard system to classify bits. Every bit manufactured anywhere in the world has a classification code based on this system. By reading the code, the driller can evaluate bits from different manufacturers and select a bit for a particular job.

The IADC classification system provides approximate information and does not describe hydraulics or features. Still, it is a simple and functional starting point for comparing bits from different manufacturers. For referencing purposes, this chapter includes examples of charts used by manufacturers to classify bits (tables 1–3):

- Table 1 is tailored to roller cone bits. This chart is used by manufacturers to classify the cutting structure, bearing type and gauge surfaces, and available features.
- Tables 2 and 3 are tailored to diamond bits. These charts are used to classify body material, cutter density, cutter size or type, and body style.

IADC provides a system for classifying roller cone bits, fixed-cutter bits, and their features.

# Dull Bit Grading



---

*In this chapter:*

- The importance of proper dull bit grading
  - Grading the condition of a bit's cutting structure
  - How to determine if a bit can drill a full-gauge hole
  - Identifying secondary bit wear
  - Understanding dull bit grading codes
- 

Dull bit grading is a way of estimating the amount and location of wear on a bit. Proper dull bit grading helps inform the rig operator or contractor in a variety of ways. For example, it can help operators select a bit that is most appropriate for specific conditions, correct poor drilling practices, and make decisions that affect the cost of future drilling. Dull bit grading is a form of ongoing field testing, which benefits operators and crewmembers.

Roller cone bits and diamond (fixed-cutter) bits are graded using an IADC dull bit classification system. The system includes eight categories (table 4). Since fixed-cutter bits have no bearings, the column for bearing wear (B) will always include an X. Notably, some wear codes only apply to diamond bits while other codes are exclusive to roller cone bits.

The first four columns on the dull bit grading chart refer only to the condition of the cutting structure. For a fixed-cutter bit, column 1 (Inner Rows) refers to the cutters within the inner, two-thirds of the diameter of the bit. For a roller cone bit, column 1 refers to the entire cutting structure except for the gauge inserts or teeth. Column 2 (Outer Rows) refers to the cutters in the outer, one-third of the diameter of a fixed-cutter bit excluding any gauge cutters. Gauge cutters for a PDC bit are not included in the system as they are frequently pre-flattened to make the bit in gauge; therefore, they have an indeterminate wear.

---

Dull bit grading:

- Helps operators select an appropriate bit
  - Is a form of field testing
  - Applies to roller cone and fixed-cutter bits
-

# Expenses to Consider



---

*In this chapter:*

- How rig operators analyze cost
  - Factors that influence cost
  - How drilling performance can minimize expenses
  - High-quality bits and long-term savings
  - Calculating operation costs
- 

Rig operators or contractors often employ a break-even analysis in order to determine the cost per foot or metre to drill a hole. In doing so, they take into account the following expenses:

- Cost to operate all aspects of the rig per hour
- Cost of the bit
- Trip time, in hours
- Drilling time, in hours

The listed expenses are impacted by the bit that is selected. For example, a PDC bit might cost 15 times as much as a steel-tooth bit and four times as much as a tungsten carbide insert bit even though the bits are equal in size. However, the bit's initial cost is just one factor. Other potential costs must be considered, such as the length of time required to drill at a certain depth and the number of trips that might be necessary. A drilling contractor will have to pay more as drilling time is extended. This could result in additional expenses, including fuel, repairs, replacement, and wages. Therefore, the upfront expense associated with a PDC bit might be offset by its long-term usefulness and durability. Moreover, PDC bits are widely used and therefore economical for many applications.

---

Expenses associated with high-end bits can be offset if the bit proves durable over time.

---

# Field Operating Procedures



---

*In this chapter:*

- Preparing a roller cone bit for a drilling operation
  - Preparing a diamond bit for a drilling operation
  - How to trip in a bit properly
  - How to achieve an optimum ROP
  - How to properly remove a bit from a borehole
- 

A roller cone bit is a durable piece of rig equipment. Still, if it is not properly handled and maintained, its life can be cut short. The following field operating procedures can assist drillers and crewmembers who are preparing to use a roller cone bit to drill a formation:

- If the packing box containing the bit is open, the threads on the bit's pin should be checked and cleaned if needed.
- The bit's serial number and type should be recorded.
- Nozzles should be checked.
- The inside of the bit should be checked for fine metallic shavings or other materials that can cause nozzles to plug.
- High-quality, clean lubricant intended for *tool joint* threads should be used on threads.
- A breaker plate, or *bit breaker*, that is appropriate for the size and shape of the bit should be used.
- The hole should be covered and the breaker placed in the locked rotary table. The bit should be screwed into the bit threads on the collar sub. The bit should be placed in the breaker and the collar or bit sub lowered over the pin.

## Drilling with a Roller Cone Bit

---

While roller cone bits are durable, they should be handled properly by crewmembers to avoid unnecessary damage.

---

# Conclusion



Although the bit is one of several mechanisms on a rig, it serves a critical purpose during the production of oil and gas. Ultimately, it should provide the rig operator with a good rate of penetration (ROP), durability, and longevity.

As detailed in this lesson, operators or contractors are responsible for selecting a bit that is most appropriate for the job. To do so, a number of factors must be considered, particularly the properties of the formation that will be drilled. Operators can choose from a variety of roller cone and fixed-cutter bits in order to achieve optimum results. Proper handling and maintenance is equally important to avoid untimely wear.

By following operating procedures accordingly—paying particular attention to rotary speed, weight, and hydraulics—a bit should function for many hours or drilling intervals, providing rig operators with an invaluable mode for drilling economically while maximizing profits.

# Appendix A



Bit wear is costly but often times avoidable. This index includes various types of wear that roller cone bits incur, possible causes and effects, and prevention tips.




**Figure 32**

*Type of wear:* Cone skidding or dragging

*Possible causes:* Bearing failure, failure to break in a cone adequately, a pinched bit, junk

*Effects:* Cone is worn flat

*Prevention:* Proper cleaning and maintenance, fish out junk



**Figure 33**

*Type of wear:* Cone erosion

*Possible cause:* Drilling fluid with abrasive particles applied at high speeds

*Effects:* Inserts fall out, ROP disrupted

*Prevention:* Adjust application of drilling fluid



**Figure 34**

*Type of wear:* Cracked cone

*Possible causes:* Erosion, ledge impact, impact on bottom

*Effects:* Cone develops cracks

*Prevention:* Proper application of drilling fluid, appropriate drilling practices

# Appendix B



All images are copyrighted and may not be reprinted, reproduced, or used in any way without the express written permission of the owner.

## Figure Credits

Figure	Owner	Web site
1_ A bit is designed to cut through layers of rock.	The University of Texas at Austin, PETEX	<a href="http://www.utexas.edu/ce/petex">www.utexas.edu/ce/petex</a>
2_ Examples of cutting structures and diamond cutters	Copyright © National Oilwell Varco. All rights reserved.	<a href="http://www.nov.com">www.nov.com</a>
3_ Circulating drilling fluid lifts cuttings.	The University of Texas at Austin, PETEX	<a href="http://www.utexas.edu/ce/petex">www.utexas.edu/ce/petex</a>
4_ Many layers of rock occur in the earth.	The University of Texas at Austin, PETEX	<a href="http://www.utexas.edu/ce/petex">www.utexas.edu/ce/petex</a>
5_ An undergauge hole has a diameter that is smaller than the bit.	The University of Texas at Austin, PETEX	<a href="http://www.utexas.edu/ce/petex">www.utexas.edu/ce/petex</a>
6_ A roller cone bit_	Copyright © Smith Bits. All rights reserved.	Not available
7_ Each cone of a roller cone bit rotates on its own axis.	The University of Texas at Austin, PETEX	<a href="http://www.utexas.edu/ce/petex">www.utexas.edu/ce/petex</a>
8_ The inner rows of teeth on one cone intermesh in the spaces between the rows of teeth on the adjacent cone.	The University of Texas at Austin, PETEX	<a href="http://www.utexas.edu/ce/petex">www.utexas.edu/ce/petex</a>
9_ A drag bit is simply two, three, or four steel blades attached to a shank.	Tim Canavan	Not available
10_ A nozzle _	Copyright © National Oilwell Varco. All rights reserved.	<a href="http://www.nov.com">www.nov.com</a>
11_ Steel teeth are milled out of the cone.	The University of Texas at Austin, PETEX	<a href="http://www.utexas.edu/ce/petex">www.utexas.edu/ce/petex</a>

# Glossary



**abrasion** *n*: a type of wear caused by friction between the rock material and bit.

A

**air bit** *n*: a roller cone bit that is specially designed for air or gas drilling. It is similar to a standard bit but includes sealed bearings to prevent clogging and a thick hardfacing on the shirrtail to protect against abrasion from high-velocity air or gas drilling fluid. Air bits usually have 0° skew angle to minimize gauge wear.

**air drilling** *n*: a method of rotary drilling that uses compressed air instead of water or drilling mud as the circulating medium; called gas drilling if compressed natural gas instead of air is circulated.

**alloy** *n*: a substance with metallic properties that comprises two or more elements in solid solution.

**annular space** *n*: the space between the drill string and the wall of the hole or the casing.

**annular velocity** *n*: the speed at which the drilling fluid is traveling in the annulus of a well.

**annulus** *n*: see *annular space*.

**antiwhirl bit** *n*: a specially designed fixed-cutter bit. An example is a bit with a smooth pad on the bit's gauge surface, positioned so that it prevents the side of the bit from biting into the formation and initiating lateral vibration. Several antiwhirl bit designs are available.

**axial force** *n*: 1. the force that travels through the center line, or axis, of the cone from the formation towards the lug. 2. to reopen the borehole with the bit.

**axial vibration** *n*: vibration mode where energy travels up and down the axis of the drill string.

**back rake angle** *n*: in a PDC bit, the angle in degrees, between vertical (90°) and the face of the cutter.

B

**back ream** *v*: 1. to enlarge the wellbore by raising and rotating the drill string that has a reamer made up in it. Backreaming enlarges tight spots in the wellbore. 2. to reopen the borehole with the bit. Backreaming is performed when clay or salt has migrated into the well behind the bit. See *ream*.

**backreaming** *n*: see *back ream*.



# Review Questions

## LESSONS IN ROTARY DRILLING

### Unit I, Lesson 2: The Bit

#### Multiple Choice

Pick the *best* answer from the choices and place the letter of that answer in the blank provided.

1. To begin drilling, a driller should rotate the bit, apply weight to it, and—
  - a. add tungsten carbide inserts.
  - b. use diamonds as cutters.
  - c. forge teeth into the cones.
  - d. circulate drilling fluid.
2. Undergauge holes—
  - a. are too large to produce efficiently.
  - b. can cause full-gauge tools to become stuck.
  - c. reduce the likelihood of bit wear.
  - d. are desirable because they are cost-effective.
3. Interfit keeps cutting structures—
  - a. sharp.
  - b. from breaking.
  - c. clean.
  - d. sandy.
4. Steel teeth should be—
  - a. long, if a roller cone bit is drilling a harder formation.
  - b. short, if a roller cone bit is drilling a harder formation.
  - c. milled from industrial-grade diamonds.
  - d. placed inside cones near the bearings.
5. Drilling fluid is—
  - a. used to cool a bit, which heats up because of friction.
  - b. always a liquid because air and gas are ineffective.
  - c. optional and not required if a bit is new.
  - d. formation fluid that enters the wellbore.
6. The primary disadvantage of tungsten carbide inserts is—
  - a. they are not very wear resistant.
  - b. they do not withstand impact shock.
  - c. they cannot withstand abrasions.
  - d. they do not last as long as steel teeth.

# Index



- abrasion
  - from drilling fluid, 40
  - from drilling mud, 36–37
  - normal wear, 45–46
  - PDC cutter, 81
  - tungsten carbide bits and, 15, 22
- abrasiveness, formation, 90
- active gauge, 75
- air and gas drilling fluids, 27, 40, 44, 83
- air bits, 83
- air drilling, 27
- alloy, 17, 35
- annular space, 1, 26, 87
- antiwhirl bits, 77, 85
- axial force, 32
  
- back rake angle, 69
- backreaming, 49
- backup studs, 73
- ball bearings, 32
- balled-up bits, 12
- ball race, 32
- barite (barium sulfate), 27
- bearing pin, 20
- bearings
  - cone interference and, 39
  - cone retention systems, 32
  - design and types of, 31
  - failure of causing cone wear, 39
  - IADC bit classification system and, 100–101
  - increasing longevity of, 36
  - in roller cone bits, 9, 17
  - journal bearing bit, 34–36
  - low-friction, 32–33
  - lubrication of, 35–38
  - reducing friction in, 31
  - in roller cone bits, 9, 17
  - wear on, 17, 48–49, 109
- bent motor assembly, 40–41, 85
- bentonite, 27
- bent sub/housing, 66
- BHA. See *bottomhole assembly (BHA)*
- bi-center bit, 86–87
- bit balling, 28
- bit breaker, 115
- bit evaluation. See *dull bit grading*
- bit gauge, 24–25
- bit record, 91
- bits
  - about, 1
  - considering costs and, 8, 113–114
  - damaged by junk, 50
  - drilling action of, 92
  - grading when dull, 107–111
  - history of, xi
  - hydraulic horsepower delivered by, 30
  - importance of breaking in, 42
  - performance of, 92
  - proper handling of, 38–39
  - selection of, xi, 5–8
  - size of, 7, 35
  - sizes of cutting structures in, 2
  - special-purpose, 83–88
- bit whirl, 77
- blades, 70, 84
- blowout, 26
- bore. See *wellbore*
- borehole. See *wellbore*
- bottomhole assembly (BHA), xi, 26, 77

## THE BIT

- bradding, 46
- brazing, 23
- brittleness, formation, 90
- broken cones, 42
- bushing, 31
- button bits. See *tungsten carbide bits*
  
- carbon, producing diamonds from, 53
- carburize, 17
- casing run time, 7
- casing strings, 87
- casting, 13
- center jet, 29
- chatter, 96. See also *vibrations*
- chipping, 80, 123
- chisel-shaped insert bit, 22
- circle plot, cutting structure, 60
- cleaning
  - PDC bits, 71
  - roller cone bits, 28–30
- cobalt chromium alloy, 35
- cold pressing, 15
- compressive strength, diamond, 54
- compressive strength, formation, 90
- computer technology, 75, 91
- concave profile, 58–59
- cone alignment, 18–19
- cone axis, 9, 18–19
- cone retention systems, 32
- cones
  - about, 17
  - cleaning, 28–30
  - heel pacs, 25
  - roller bit, 9
- cone-shaped insert bit, 22
- cone shell, 20
- cone shell erosion, 44–45
- cone wear. See also *roller cone bits; wear*
  - causes, 38–39
  - coring, 42, 122
  - erosion, 39–40, 121
  - interference, 39
  - off-center wear, 41–42, 122
  - preventing, 42
  - skidding/dragging, 39, 121
- copper inlay, 38
- core, examining, 91
- core bits, 87
- coring, 42, 122
- corrosion, 48
- cost per interval, 114
- cracked cones, 39–40, 121
- cross-pad flow channel, 62–63
- crow's foot, 62
- cutters. See *polycrystalline diamond compact (PDC) bits*
- cuttings, 1, 3
- cutting structures
  - cone alignment and, 19–20
  - diamond bits, 57, 60–61
  - gauge, 24–25
  - IADC bit classification system and, 100–101
  - powder-forged, 23
  - roller cone bits, 21–23
  - self-sharpening, 21
  - steel teeth, 21
  - tungsten carbide inserts, 22–23
- cutting structure wear. See also *wear*
  - broken insert, 44
  - broken teeth, 43–45
  - by formation changes, 44
  - causes, 42–43
  - causing bearing breakdown, 49
  - chipping, 43
  - cone shell, 44–45
  - erosion, 44
  - flat-crested wear, 45, 124
  - gauge rounding, 47–48, 125
  - heat checking, 47, 80–81, 124
  - normal, 43
  - self-sharpening, 45–46, 124
  - tracking, 46–47, 124
  - tungsten carbide inserts, 43

- delamination, 80
- depositional environment, 6
- DiamondBacks™, 74
- diamond bit design
- cutting structures, 60–61
  - hydraulics, 62–63
  - overview of, 57–58
  - profiles, 58–59
- diamond bits. See also *fixed-cutter bit*
- about, 53–54
  - blades on, 70
  - dull bit grading, 107–111
  - field operating procedures, 116–117
  - IADC bit classification system and, 102, 104
  - natural and impregnated, 56
  - optimal use of, 92
  - optimal WOB and RPM for, 97
  - overview of, 57
  - PDC, 64–72
  - types of, 54
- diamond bit wear. See also *wear*
- causes, 76
  - drilling junk, 79, 125
  - proper maintenance of, 76–77
  - spiral-shaped holes, 79
  - vibrations, 78
- diamond compacts (cutters), 1–2, 66
- diamond grit, 66–67
- diamond impregnated bits
- about, 56–58
  - IADC bit classification system and, 102
  - manufacture of, 61
  - optimal use of, 92
  - studs, 72–73
- diamonds
- about, 53, 56
  - advantages of, 54–55
  - grades and sizing, 56
  - industrial, 56
  - limitations of, 55–56
  - natural, 53, 56
  - polycrystalline, 54
  - properties of, 54–55
  - size in cutting structure, 61
  - thermally stable polycrystalline (TSP), 54
- diamond table, 66
- diamonds, synthetic, 53
- directed nozzles, 29
- directional drilling, 86
- double-cone profile, 58–59
- downhole motor, 66, 85
- drag bits, 11, 64
- drill collar, 42
- driller's log, 91, 111
- drilling
- improving efficiency, 10
  - performance, 114
  - rates of, 95–96
- drilling fluid
- abrasive particles in, 40
  - circulation of, 26
  - hydrogen sulfide in, 48
  - in diamond bits, 62
  - overview of, 1, 3
  - reactive and nonreactive material in, 27
  - roller cone bits and, 26–27
  - using air and gas in, 27, 40, 44, 83
  - wear and, 49
- drilling mud, 26–27, 36
- drill stem, 75
- drill string, 1, 26
- dual-action gauge, 75
- dull bit grading, 107–111
- eccentric bits, 86
- ECD. See *equivalent circulating density (ECD)*
- elasticity, formation, 90
- elastomer rings, 37
- Eleventh General Conference on Weights and Measures, xvi
- English system of measurement, xvi–xvii
- equivalent circulating density (ECD), 87
- erosion
- by drilling fluid, 49

## THE BIT

- cone, 39–40, 44, 121
- early roller cone bits, 12
- flame spray and, 45
- PDC bits, 64–65
- PDC cutter, 80–81
- extended nozzles, 29, 49
- feeder-collector channel, 62–63
- field operating procedures
  - diamond bits, 116–117
  - roller cone bits, 115–116
- fishtail bits, 11
- fixed-cutter bit, xi, 57, 64, 85–87, 107–108. See also *diamond bits*
- flame spray, 45
- flanges, 33
- flat-crested wear, 45, 124
- forging, 13
- formation (rock). See also *lithology*
  - about, xi, 6
  - analysis of, 91
  - bit profiles and, 58–59
  - causing bearing wear, 49
  - causing cutting structure wear, 44
  - cone alignment and, 20
  - diamond bits and, 57
  - hardness, 7
  - IADC bit classification system and, 100–101
  - plastic, 46
  - polycrystalline diamond (PDC) bits, 97
  - proper WOB and, 96–97
  - properties of, 90
  - shearing v. crushing, 64
  - teeth size and, 21
  - tungsten carbide insert bits, 22
  - types of bits for, 11
  - using backup studs, 73
- friction
  - bearings and, 31, 35–36
  - bit wear and, 78
  - self-lubricating systems, 38
  - friction bearing, 31
  - friction force, 55
  - full-gauge hole, 7
  - FuseTek™ bit, 74
- gauge areas, 24–25, 62
- gauge cutters. See also *fixed-cutter bit*
- gauge cutting structure, 24, 47
- gauge hole, 110
- gauge inserts, 25
- gauge pad, 85
- gauge rounding, 47–49, 125
- gauge row. See *gauge cutting structure*
- gauges, 24, 48, 74–75
- gauge surface, 100–101
- gauge teeth, 24
- General Electric, 53
- grease reservoir, 37
- grid plot, cutting structure, 60
- hardfacing, 14, 46, 64, 83
- hard metal, 21
- hardness, diamond, 54
- hardness, formation, 7, 90
- heat checking, 47, 80–81, 124
- heel pacs, 25
- hemispherical insert bit, 22
- hot pressing, 15
- Hughes, Howard, Sr., ix
- hybrid bits, xi, 73, 102
- hydraulic horsepower (hhp), 30
- hydraulic horsepower per square inch (HSI), 30
- hydraulics
  - diamond bits, 62–63
  - PDC bits, 71–72
  - roller cone bits and, 26–27
- hydrogen sulfide, 48
- IADC. See *International Association of Drilling Contractors (IADC)*

- impact shock  
     diamond bits and, 55–56  
     tungsten carbide bits and, 15, 22
- industrial diamonds, 56
- inner bearings, 49
- insert bits. See *tungsten carbide inserts*
- insert land, 23
- inserts. See also *tungsten carbide inserts*  
     about, 2  
     broken, 44, 123  
     cone alignment and, 19  
     in roller cone bits, 9  
     losing, 44
- inside diameter (ID), 34
- interference, cone, 39
- interference fit, 23
- interfit, 20
- International Association of Drilling Contractors (IADC)  
     bit classification system, 99–104  
     dull bit grading, 107–108  
     on jet nozzle measurement, 28  
     on recording conditions of used bits, 38
- islands (interrupted blades), 63
- jet deflection bit, 84
- jet nozzles  
     design and manufacture, 72  
     for jet deflection bits, 84  
     hydraulic cleaning power of, 30  
     in roller cone bits, 28–29  
     PDC bits, 71–72  
     placement of, 29  
     size recommendations for, 28, 30
- journal, 31
- journal angle, 20
- journal bearing, 31
- journal bearing bit, 34–36, 100–101
- junk  
     causing bit wear, 50, 125  
     causing cone wear, 39  
     cleaning out of hole before using new bit, 116  
     importance of care to avoid drilling, 79
- junk slots, 71
- junk sub, 44
- kerfs, 41
- kick, 26, 87
- lateral vibrations, 41, 74, 77
- lithology, 6. See also *formation (rock)*
- load force, 36
- long substrate (LS) bond failure, 80
- low-friction bearing, 31–32
- low-friction gauge pad, 85
- lubrication, 35–38, 115
- lug (leg), 17
- makeup tongs, 116
- matrix, 57, 61, 102
- measurement systems, xvi–xvii
- metal rings, 37
- metric system, xvi–xvii
- milled-tooth bit. See *steel-tooth bits*
- modulus of elasticity, 54
- mud cooled bit, 36–37
- mud pits, 26
- mud pumps, 26
- natural diamond bits, 56–58, 61
- non-planar interfaces (NPIs), 67
- nonsealed bearings, 36, 109
- nose (cone), 32
- nozzle pods, 12
- off-center wear, 41–42, 122
- offset alignment, 18–19
- on-center alignment, 18–19
- outer bearings, 48
- outside diameter (OD), 34
- overburden pressure, 90–91

## THE BIT

- overgauge hole, 41
- oxidation of a diamond, 55
- parabolic profile, 58–59, 65
- PDC bits. See *polycrystalline diamond compact (PDC) bits*
- PDC cutter. See *polycrystalline diamond compact (PDCs) cutter*
- permeability, formation, 90
- pin angle, 20
- pinched bit, 39
- plasticity, formation, 90–91
- polycrystalline diamond compact (PDC) bits
  - considering costs and, 113–114
  - cutters, 66–70
  - design and manufacture, 76
  - IADC bit classification system and, 103
  - maintenance of, 76
  - manufacture and design, 64–65
  - new bit designs, 72–74
  - optimal use of, 92
  - other components in, 74–75
  - overview of, 64
  - round-topped inserts, 74
  - wear, 76–81
  - WOB and RPM for, 97
- polycrystalline diamond compact (PDCs) cutter
  - about, 66–70
  - blades, 70
  - hydraulics, 71–72
  - IADC bit classification system and, 102–103
  - wear on, 80–81
- polycrystalline diamonds, 54
- pore pressure, 90
- porosity, formation, 90
- positive displacement motor (PDM), 66, 84
- powder-forged bits, 15, 25
- powder-forged cutting structures, 23
- pressure compensator, 37
- profiles, diamond bits, 58–59, 65–66, 102, 104
- quench, 17
- radial flow channel, 62
- rake angle, 69
- rate of penetration (ROP)
  - adequate cleaning and, 28
  - bit selection and, xi, 7
  - diamond bits, 97
  - drilling fluids and, 27
  - hydraulic horsepower (hhp) and, 30
  - off-center wear and, 41
  - UBD and, 27
- reaming, 7, 79
- reservoir, 6
- retention systems, 32, 35
- revolutions per minute (RPM)
  - for diamond bits, 97
  - for polycrystalline diamond (PDC) bits, 97
  - for roller cone bits, 96–97
  - importance of proper adjustment of, 95
- ridge set, 61
- rig owner/operators, xi, 38, 113–114
- rig time, bit selection and, 7
- ring gauge, 110
- rock. See *formation (rock)*
- rock bits, xi
- roller bearing, 31
- roller bearing bits, 32–33, 100–101
- roller cone bits. See also *cone wear*
  - about, 9–10, 15
  - bearings, 31–38
  - bit gauge, 25
  - cleaning, 28–30
  - cones, 17–20
  - cutting structure wear, 42–47
  - cutting structures of, 21–23
  - drilling fluid and hydraulics, 26–27
  - dull bit grading, 107–111
  - field operating procedures, 115–116
  - history of, 11–12
  - IADC bit classification system for, 100–101
  - manufacture and design, xi, 16
  - optimal use of, 92
  - optimal WOB and RPM for, 96–97

- powder-forged bits, 15
- special-purpose, 83–85
- steel-tooth, 13
- tungsten carbide, 14–15
- wear on, 38–50
- ROP. See *rate of penetration (ROP)*
- rotary steerable system (RSS), 75, 85–86
- rotors, 84
- round profile, 58–59
- round-top PDC inserts, 74
- RPM. See *revolutions per minute (RPM)*
- sealed bearings, 36–38, 48, 109
- seal gland, 37
- seal land, 37
- self-lubricating systems, 38
- self-sharpening, 66
- self-sharpening wear, 45–46, 124
- shallow-cone profile, 65
- Sharp, Walter, ix
- shear bit, 57
- short parabolic profile, 65
- shoulder (bit), 86
- side jets, 29
- side rake angle, 69
- sidetracking bits, 87
- single-cone profile (round), 58–59
- sinter, 66
- skewed cones, 19
- skidding/dragging, cone, 39, 121
- spalling, 31, 80–81
- special-purpose bits
  - fixed-cutter bit, 85–87
  - roller cone, 83–85
- spiral-shaped holes, 79
- split central nozzle, 29
- stators, 84
- steel, 16–17
- steel body, 102
- steel-teeth, 2, 21
- steel-tooth bits
  - about, 13
  - and hard formations, 21
  - IADC bit classification system and, 100–101
  - self-sharpening, 21
  - tungsten carbide and, 21
  - tungsten carbide application to, 14
- stickiness, formation, 90
- stick-slip, 78
- stiff drilling assembly, 42
- stringers, 65
- studs, 72–73
- surface piping, 26
- surface set, 61
- surface-to-surface contact, 34
- surfactant, adding, 27
- Système International (SI) d'Unites, xvi–xvii
- taper (bit), 86
- teeth
  - broken, 43–45, 123
  - cone alignment and, 19
  - in roller cone bits, 9–10
  - interfit, 20
  - reasons for wear on, 43
  - self-sharpening, 21, 45–46
- temper, 17
- thermal (heat) conductivity, diamond, 55
- thermal instability, diamond, 55
- thermally stable polycrystalline (TSP), 54, 73, 102, 104
- thermal stability, diamond, 67–68, 71
- three-cone bits, 12, 83
- torque, 74, 78
- torsional vibration, 74, 78
- total depth (TD), costs to reach, 114
- tracking, 41, 46–47, 124
- trimmers. See *gauge inserts*
- triple port center jet, 29
- tripping in, 116–117
- tripping out, 75



## THE BIT

- trips, 7
- TSP. See *thermally stable polycrystalline (TSP)*
- tungsten carbide
  - flame spray, 45
  - in insert bits, 25
  - in roller cone bit nozzles, 12
  - on PDC cutters, 66–67
  - on steel-teeth, 21
  - PDC bits and, 64
  - properties of, 16
  - vs. steel, 16
  - wear and, 43, 46
- tungsten carbide bits
  - about, 14–15
  - abrasion resistance of, 14
  - considering costs and, 113–114
- tungsten carbide inserts. See also *inserts*
  - about, 22–23, 25
  - composition, 22
  - IADC bit classification system and, 100–101
  - shapes of, 22
- turbine motors, 84
- turbine sleeves, 86
- two-cone roller bit, 12, 83
  
- underbalanced drilling (UBD), 27
- undergauge hole
  - about, 7
  - eccentric bits and, 86
  - pinching and, 39
  - problems with, 7
  - wear and, 49
- unsealed bearings, 37
- up-reaming cutters, 75
  
- vibrations
  - bit whirl, 77
  - causing wear, 48
  - reducing, 69
  
- round-topped PDC inserts and, 74
- torsional, 78
  
- washout, 12, 49, 50, 125
- washpipe, 12
- watercourses
  - cleaning roller cone bits and, 28
  - erosion of, 12
  - in a diamond bit, 62–63
  - in the roller cone bit, 12
- wear. See also *cone wear; cutting structure wear; diamond bit wear*
  - actions causing, 38
  - bearings, 48–49
  - cone, 39–42
  - cutting structures, 42–48
  - diamond bits and, 54
  - diamonds, 61
  - drilling fluid and, 49
  - dull bit grading, 107–111
  - evaluating, 38
  - examples of, 121–125
  - gauge areas, 25
  - nozzles and, 49
  - PDC cutter, 80–81
  - polycrystalline diamond (PDC) bits, 76–81
- weight on the bit (WOB)
  - back angle and, 69
  - for diamond bits, 97
  - for polycrystalline diamond (PDC) bits, 97
  - for roller cone bits, 96–97
  - importance of proper adjustment of, 95
  - on-center alignment and, 19
  - wear and, 49
- wellbore, 25
- wells, tripping out, 75
- whirling, 41
- wildcat well, 5
- wireline, 87
- WOB. See *weight on the bit (WOB)*

---

To obtain additional training materials, contact:

**PETEX**  
THE UNIVERSITY OF TEXAS AT AUSTIN  
PETROLEUM EXTENSION SERVICE

J.J. Pickle Research Campus  
10100 Burnet Road, Bldg. 2  
Austin, TX 78758

Telephone: 512-471-5940  
or 800-687-4132

FAX: 512-471-9410  
or 800-687-7839

E-mail: [petex@www.utexas.edu](mailto:petex@www.utexas.edu)  
or visit our Web site: [www.utexas.edu/ce/petex](http://www.utexas.edu/ce/petex)



---

To obtain information about training courses, contact:

**PETEX**  
LEARNING AND ASSESSMENT CENTER  
THE UNIVERSITY OF TEXAS

4702 N. Sam Houston Parkway West, Suite 800  
Houston, TX 77086

Telephone: 281-397-2440  
or 800-687-7052

FAX: 281-397-2441

E-mail: [plach@www.utexas.edu](mailto:plach@www.utexas.edu)  
or visit our Web site: [www.utexas.edu/ce/petex](http://www.utexas.edu/ce/petex)

---

Petroleum Extension-The University of Texas at Austin

Petroleum Extension-The University of Texas at Austin

ISBN 10: 0-88698-243-X  
ISBN 13: 978-0-88698-243-0



9 780886 982430

2-10250  
0-88698-243-X